

COMPONENTS



Base Unit



Feather Toy (installed)




Mouse Toy

BATTERY INSTALLATION


STEP 1

Remove the battery cover from bottom of the base unit. Using a Phillips head screwdriver turn screw counter clockwise.



STEP 2

Insert 4 C batteries (not included) into the battery compartment as shown, then re-attach battery cover.



Install batteries according to the polarity indicated inside compartment.

USE

STEP 3

Place base unit on designated flat surface. Press the power button, and your Pop N Play™ is ready for use. Press the sound button for optional chirping sounds.



Power Button Sound Button

NOTE: This unit features an Auto Off function that will turn the unit off automatically after 15 minutes of use.

CHANGING TOYS:

Press and hold the Power and Sound buttons for 3 seconds. Toy will extend out from base unit. Unscrew mouse toy by turning counterclockwise to remove. Install desired toy by turning clockwise.



! WARNING:

- 1) Do not mix old and new batteries.
- 2) Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc) batteries.

CHOKING HAZARD

Keep out of reach of children. Do not allow children to play with or near this item. This is not a toy for children. If product becomes damaged, please discard immediately.

Important: Inspect products frequently. Supervised use only. Discontinue use if worn, loose or torn pieces occur or become damaged. For cats only. Keep away from dogs and other household pets. Do not use this product for anything other than its intended use.

Care Instructions : Wipe outside with a clean, moist towel. Dry thoroughly. Do not immerse in water.

FOR HELPFUL TIPS AND INSTRUCTIONAL VIDEOS OR TO PURCHASE ADDITIONAL TOYS PLEASE VISIT: WWW.PETSKNOWBESTTIPS.COM

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-3(B) / NMB-3(B)

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.